

# **Operating Instructions**

# for

# Variable area flow meter

# Model: URM



# 1. Contents

1.	Contents	2
2.	Note	3
3.	Instrument Inspection	3
4.	Regulation Use	3
5.	Operating Principle	4
6.	Mechanical Connection	4
7.	Electrical Connection	5
	7.1 Inductive switch (option)	5
8.	Operation	5
9.	Maintenance	5
10.	Technical Information	6
11.	Order Codes	6
12.	Dimensions	6
13.	Disposal	6
14.	EU Declaration of Conformance	7
15.	EU Declaration of Conformance (contact)	8

## Manufactured by:

Kobold-Unirota Ltd. 4400 Nyíregyháza Derkovits út 132-136. Tel.: +36-42-342-215 Fax: +36-42-500-175 E-Mail: <u>info.hu@kobold.com</u> Internet: <u>www.unirota.hu</u>

### Sold by:

Kobold Messring GmbH Nordring 22-24 D-65719 Hofheim Tel.: +49(0)6192-2990 Fax: +49(0)6192-23398 E-Mail: <u>info.de@kobold.com</u> Internet: <u>www.kobold.com</u>

## 2. Note

Please read these operating instructions before unpacking and putting the unit into operation. Follow the instructions precisely as described herein.

The instruction manuals on our website <u>www.kobold.com</u> are always for currently manufactured version of our products. Due to technical changes, the instruction manuals available online may not always correspond to the product version you have purchased. If you need an instruction manual that corresponds to the purchased product version, you can request it from us free of charge by email (<u>info.de@kobold.com</u>) in PDF format, specifying the relevant invoice number and serial number. If you wish, the operating instructions can also be sent to you by post in paper form against an applicable postage fee.

Operating instructions, data sheet, approvals and further information via the QR code on the device or via <u>www.kobold.com</u>

The devices are only to be used, maintained and serviced by persons familiar with these operating instructions and in accordance with local regulations applying to Health & Safety and prevention of accidents.

When used in machines, the measuring unit should be used only when the machines fulfil the EC-machine guidelines.

## 3. Instrument Inspection

Instruments are inspected before shipping and sent out in perfect condition. Should damage to a device be visible, we recommend a thorough inspection of the delivery packaging. In case of damage, please inform your parcel service / forwarding agent immediately, since they are responsible for damages during transit.

### Scope of delivery:

The standard delivery includes:

- Variable area flow meter model: URM
- Inductive switch (option)

# 4. Regulation Use

Any use of the device, which exceeds the manufacturer's specification, may invalidate its warranty. Therefore, any resulting damage is not the responsibility of the manufacturer. The user assumes all risk for such usage.

# 5. Operating Principle

The Kobold URM model flowmeter/monitor works on the basis of the suspended float principle. It is used for measuring the flow rates in closed pipe line systems.

The medium flows from below through a glass measuring cone that gets wider on top. Thus, the float is raised and indicates the respective flow rate on the scale provided on the measuring cone. To monitor flow rate limits, the URM meters can be optionally furnished with "open collector" proximity switches.

By its special design, this model is particularly suitable for applications where only very small operating pressures are available. Another advantage is offered by the very large sight glass which optically allows direct flow observation.

# 6. Mechanical Connection

## **Before Installation:**

- Remove all transportation safety locks and ensure that no packing material remains within the unit.
- Be sure that the maximum allowable operating pressure and temperature is not exceeded (see Technical data).
- Install the flow meter in the piping system, ensure the instrument is under no mechanical stress/tension (install support bracing if necessary).
- Protect the measuring tube from external damage.
- Avoid pressure peaks in the measuring tube, e.g. from sudden surges or stoppage of flow.
- If possible, immediately after making mechanical connections, check whether the connections are properly sealed with no evidence of leakage

# 7. Electrical Connection

## 7.1 Inductive switch (option)



Caution! Make sure that the voltage values of your system correspond with the voltage values of the measuring unit.

- Make sure that the supply wires are de-energized.
- Plug in the system according to the connecting diagrams.
- 7.1.1 We recommend the use of wires with cross sectional area of min. 0.25 mm<sup>2</sup>



Attention! Incorrect wiring will lead to damage of the unit's electronics.

### 7.1.1.1 Wiring diagram



# 8. Operation

In order to initialise the inductive switch function, it is essential that the float activates the contact once in each direction.

Adjustment of limit-values

The switch-point can be adjusted to the desired levels by using.

Reference edge: approx. the middle of the sensor.

Slide the switch housing up or down until the reference edge coincides with the desired switch-point scale reading.

#### Overranging

With non-pulsating flow, the maximum flow rate can be exceeded. Only an increase in pressure loss will result (max. permissible operating pressure must not be exceeded!)

# 9. Maintenance

If the medium to be measured is clean, the series URM is virtually maintenancefree. If deposits form on the inner housing or parts, periodic cleaning of the unit is recommended. Remove the units from the piping with a suitable tool; clean the flow meter with a suitable cleaning agent or make use of an ultrasonic bath.

# **10. Technical Information**

Operating instructions, data sheet, approvals and further information via the QR code on the device or via <u>www.kobold.com</u>

## 11. Order Codes

Operating instructions, data sheet, approvals and further information via the QR code on the device or via <u>www.kobold.com</u>

## 12. Dimensions

Operating instructions, data sheet, approvals and further information via the QR code on the device or via <u>www.kobold.com</u>

## 13. Disposal

## Note!

- Avoid environmental damage caused by media-contaminated parts
- Dispose of the device and packaging in an environmentally friendly manner
- Comply with applicable national and international disposal regulations and environmental regulations.

### **Batteries**

Batteries containing pollutants are marked with a sign consisting of a crossed-out garbage can and the chemical symbol (Cd, Hg, Li or Pb) of the heavy metal that is decisive for the classification as containing pollutants:



## Electrical and electronic equipment



## **14. EU Declaration of Conformance**

We, KOBOLD Unirota Kft. Nyíregyháza Hungary, declare under our sole responsibility that the product:

Variable area flow meter Model: URM-...

to which this declaration relates is in conformity with the standards noted below:

**EN IEC 63000:2018** Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances

Also, the following EC guidelines are fulfilled:

2011/65/EU 2015/863/EU **RoHS** (category 9) Delegated Directive (RoHS III)

Nyíregyháza, 31 January 2023

Dénes Szabó General Manager

# 15. EU Declaration of Conformance (contact)

EU-Kor EU Declara	nformitätserklärun tion of Conformity No.:	g Nr.:	5020-2M	TURCK		
Wir/We:	HANS TURCK GMBH & CO KG WITZLEBENSTR. 7, 45472 MÜLHEIM A.D. RUHR					
erklären ir declare unde	n alleiniger Verantwortung, d er our sole responsibility that the pro-	ass die Pro oducts	odukte			
Induktive, kapazitive, magnetische und Ultraschall- Näherungsschalter: Inductive, capacitive, magnetic and ultrasonic proximity switches:		Der Typen beginnend mit: types starting with: BI, NI, S32SR, SI, WI, BR, MP, DBI, DNI, DTBI, DTNI, BC, NC, RU, WIM, BIM				
auf die sic folgenden to which this standards:	ch die Erklärung bezieht, der Normen genügen: declaration relates are in conformi	Anforderu	ungen der folgenden EU-R quirements of the following EU-di	ichtlinien durch Einhaltung der rectives by compliance with the following		
EMV - Ric EN 60947	htlinie /EMC Directive -5-2:2007/A1:2012		2014 / 30 / EU	26.02.2014		
RoHS – R EN 50581	tichtlinie /RoHS Directive		2011 / 65 / EU	08.06.2011		
Niederspannungsrichtlinie /Low Voltage Directive EN 60947-5-2:2007/A1:2012			2014 / 35 / EU	26.02.2014		

(für die Geräte mit Versorgungsspannung / for equipment with supply voltage: >50V AC bzw. >75V DC)

Weitere Normen, Bemerkungen: additional standards, remarks:

Zusätzliche Informationen: Supplementary infomation:

Mülheim a. d. Ruhr, den 29.01.2019

Ort und Datum der Ausstellung / Place and date of issue

i.V. Dr. M. Linde, Leiter Zulassungen /Manager Approvals Name, Funktion und Unterschrift des Befugten / Name, function and signature of authorized person

.