

Operating Instructions for

Optical Level Sensor

OPT-Y24896/0001 OPT-Y24896/0002



1. Contents

1.	Contents	.2	
2.	Note	.3	
3.	Instrument Inspection	.3	
4.	Regulation Use	.3	
	Operating Principle		
6.	Mechanical Connection	.5	
	6.1 Process Connection G ¹ / ₂ (OPT)		
	Electrical Connection		
	7.1 General Information	.6	
	7.2 Terminal Connection Diagrams	.6	
11.	Disposal	.8	
12.	EU Declaration of Conformance	.9	
13.	13. UK Declaration of Conformity10		

Manufactured and sold by:

Kobold Messring GmbH Nordring 22-24 D-65719 Hofheim, Germany Tel.: +49 (0)6192-2990 Fax: +49(0)6192-23398 E-mail: info.de@kobold.com Internet: www.kobold.com

2. Note

Please read these operating instructions before unpacking and putting the unit into operation. Follow the instructions precisely as described herein.

The instruction manuals on our website <u>www.kobold.com</u> are always for currently manufactured version of our products. Due to technical changes, the instruction manuals available online may not always correspond to the product version you have purchased. If you need an instruction manual that corresponds to the purchased product version, you can request it from us free of charge by email (<u>info.de@kobold.com</u>) in PDF format, specifying the relevant invoice number and serial number. If you wish, the operating instructions can also be sent to you by post in paper form against an applicable postage fee.

The devices are only to be used, maintained and serviced by persons familiar with these operating instructions and in accordance with local regulations applying to Health & Safety and prevention of accidents.

When used in machines, the measuring unit should be used only when the machines fulfil the EC-machine guidelines.

3. Instrument Inspection

All Instruments are inspected before shipping and sent out in perfect condition. Should damage to a device be visible, we recommend a thorough inspection of the delivery packaging. In case of damage, please inform your parcel service / forwarding agent immediately, since they are responsible for damages during transit.

Scope of delivery:

The standard delivery includes:

• Optical Level Sensor model: OPT-Y24896/0001 / OPT-Y24896/0002

4. Regulation Use

Any use of the Optical Level Sensor, model: OPT, which exceeds the manufacturers specification may invalidate its warranty. Therefore, any resulting damage is not the responsibility of the manufacturer. The user assumes all risk for such usage.

5. Operating Principle

The optical level sensors of model OPT have been developed for monitoring **transparent** liquids. Due to the very small dimensions, very slight switching hysteresis and high repeatability, the instruments are also suited for service in small vessels. The optical sensor is situated in a robust housing. It comprises a plastic hollow hemisphere, in which the infrared diode is fitted as a transmitter and a semiconductor as a receiver. When the sensor is not wetted by liquid, the infrared light is reflected fully from the surface of the hemisphere to the receiver. As soon as the sensor is covered with liquid, the refractive index on the boundary layer changes and most of the light escapes into the liquid. Less light then reaches the receiver, which allows switching to take place. The level probe should not be fitted with the sensor pointing downwards, as errors can occur due to drops of liquid sticking to it.

6. Mechanical Connection

Before installation:


Make sure that the maximum operating pressures and temperatures allowed for this device are not exceeded (see Fehler! Verweisquelle konnte nicht gefunden werden.. Fehler! Verweisquelle konnte nicht gefunden werden.).

Avoid mounting the Optical Level Sensor vertically downward from the top of the container cover. In this position, drops accumulating on the optical sensor can cause the sensor to report an apparent, false, simulated level (switching point reached).

Recommended mounting positions:

- On the side wall of the tank
- Vertically upward on the bottom of the tank

6.1 Process Connection G ¹/₂ (OPT-...)



Seal the device in the side of the container with Teflon tape or similar sealant.

7. Electrical Connection

7.1 General Information




Attention! Make sure that the voltage values of your system correspond with the voltage values of the measuring unit.



Make sure that the supply wires are de-energised.

7.2 Terminal Connection Diagrams



8. Technical Information

Operating instructions, data sheet, approvals and further information via the QR code on the device or via <u>www.kobold.com</u>

9. Order Codes

Operating instructions, data sheet, approvals and further information via the QR code on the device or via <u>www.kobold.com</u>

10. Dimensions

Operating instructions, data sheet, approvals and further information via the QR code on the device or via <u>www.kobold.com</u>


11. Disposal

Note!

- Avoid environmental damage caused by media-contaminated parts
- Dispose of the device and packaging in an environmentally friendly manner
- Comply with applicable national and international disposal regulations and environmental regulations.

Batteries

Batteries containing pollutants are marked with a sign consisting of a crossed-out garbage can and the chemical symbol (Cd, Hg, Li or Pb) of the heavy metal that is decisive for the classification as containing pollutants:



- 1. "Cd" stands for cadmium
- 2. "Hg" stands for mercury
- 3. "Pb" stands for lead
- 4. "Li" stands for lithium

Electrical and electronic equipment



12. EU Declaration of Conformance

We, KOBOLD Messring GmbH, Nordring 22-24, 65719 Hofheim, Germany, declare under our sole responsibility that the product:

Optical Level Sensor model: OPT –Y24896/0001 / OPT-Y24896/0002

to which this declaration relates is in conformity with the following EU directives stated below:

2014/30/EU	EMC Directive
2011/65/EU	RoHS (category 9)
2015/863/EU	Delegated Directive (RoHS III)

Also, the following standards are fulfilled:

EN 61000-4-4:2012

Electromagnetic compatibility (EMC) - Part 4-4: Testing and measurement techniques - Electrical fast transient/burst immunity test, BURST 2 kV

EN 61000-4-2:2009

Electromagnetic compatibility (EMC) - Part 4-2: Testing and measurement techniques - Electrostatic discharge immunity test, ESD 4 kV/8 kV

EN IEC 63000:2018 Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances

Hofheim, 10 October 2023

H. Volz General Manager

J. Burke Compliance Manager

13. UK Declaration of Conformity

We, KOBOLD Messring GmbH, Nordring 22-24, 65719 Hofheim, Germany, declare under our sole responsibility that the product:

Optical Level Sensor model: OPT –Y24896/0001 / OPT-Y24896/0002

to which this declaration relates is in conformity with the following UK directives stated below:

S.I. 2016/1091Electromagnetic Compatibility Regulations 2016S.I. 2012/3032The Restriction of the Use of Certain Hazardous
Substances in Electrical and Electronic Equipment
Regulations 2012

Also, the following standards are fulfilled:

BS EN 61000-4-4:2012

Electromagnetic compatibility (EMC). Testing and measurement techniques. Electrical fast transient/burst immunity test, BURST 2 kV

BS EN 61000-4-2:2009

Electromagnetic compatibility (EMC). Testing and measurement techniques. Electrostatic discharge immunity test, ESD 4 kV/8 kV

BS EN IEC 63000:2018

Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances.

Hofheim, 10 October 2023

H. Volz General Manager

J. Burke Compliance Manager