

# **Operating Instructions for Rotating-Vane Flow Indicator**

**Model: DIG**



## 1. Contents

---

1. Contents.....	2
2. Note .....	3
3. Regulation Use .....	3
4. Operating Principles.....	3
5. Instrument Inspection.....	4
6. Mechanical Connection.....	4
7. Technical Information.....	5
8. Order Codes .....	5
9. Dimensions .....	5
10. Disposal .....	6
11. EU Declaration of Conformance .....	7
12. UK Declaration of Conformity.....	8

### Manufactured and sold by:

Kobold Messring GmbH  
Nordring 22-24  
D-65719 Hofheim/Germany  
Tel.: +49(0)6192-2990  
Fax: +49(0)6192-23398  
E-mail: [info.de@kobold.com](mailto:info.de@kobold.com)  
Internet: [www.kobold.com](http://www.kobold.com)

## **2. Note**

---

Please read these operating instructions before unpacking and putting the unit into operation. Follow the instructions precisely as described herein.

The instruction manuals on our website [www.kobold.com](http://www.kobold.com) are always for currently manufactured version of our products. Due to technical changes, the instruction manuals available online may not always correspond to the product version you have purchased. If you need an instruction manual that corresponds to the purchased product version, you can request it from us free of charge by email ([info.de@kobold.com](mailto:info.de@kobold.com)) in PDF format, specifying the relevant invoice number and serial number. If you wish, the operating instructions can also be sent to you by post in paper form against an applicable postage fee.

Operating instructions, data sheet, approvals and further information via the QR code on the device or via [www.kobold.com](http://www.kobold.com)

The devices are only to be used, maintained and serviced by persons familiar with these operating instructions and in accordance with local regulations applying to Health & Safety and prevention of accidents.

When used in machines, the measuring unit should be used only when the machines fulfil the EC-machine guidelines.

### **as per Pressure Equipment Directive 2014/68/EU**

In acc. with Article 4 Paragraph (3), "Sound Engineering Practice", of the PED 2014/68/EU no CE mark.

Diagram 8, Piping, Group 1, Dangerous Fluids

## **3. Regulation Use**

---

Any use of the Rotating-Vane Flow Indicator, model: DIG, which exceeds the manufacturer's specification, may invalidate its warranty. Therefore, any resulting damage is not the responsibility of the manufacturer. The user assumes all risk for such usage.

## **4. Operating Principles**

---

A plastic-rotating vane wheel rotates on an axle shaft in accordance with the flow. The presence or absence of rotary motion indicates whether there is flow or not.

## 5. Instrument Inspection

---

Instruments are inspected before shipping and sent out in perfect condition. Should damage to a device be visible, we recommend a thorough inspection of the delivery packaging. In case of damage, please inform your parcel service / forwarding agent immediately, since they are responsible for damages during transit.

### **Scope of delivery:**

The standard delivery includes:

- Flow Indicator      model: DIG

## 6. Mechanical Connection

---

### **Before installation**



- Make sure that the actual throughput in the installation matches the scale range of the device. The device capacity is indicated on the nameplate.

---

**Caution! If the capacity of the device is exceeded by more than 20%, its bearings will be damaged.**

---

- Make sure that the maximum operating pressure and temperature of the device are not exceeded.
- Remove all packing materials and transport retainers and ensure that no such materials remain in the device.
- These devices can be installed in any required position. The direction of flow must always be in the direction indicated by the arrow. The front of the device must always be vertical.
- In cases where the flow is running from top to bottom, take particular care to ensure that the device housing is completely filled with fluid. Additional inlet and outlet pipe sections are not required.

**Wrong!****Right**

- The threaded connections must be sealed with Teflon tape or similar sealant.
- During installation, avoid placing pressure and tension loads on the device. We recommend that the inlet and outlet lines be mechanically secured at a distance of approximately 50 mm from the connections.
- If possible, immediately after completing the mechanical installation, check the threaded connections between the device and piping for leaks.

---

**Caution! Be sure to tighten the fittings at the device only with the correctly sized open-end wrench.**

---

## 7. Technical Information

---

Operating instructions, data sheet, approvals and further information via the QR code on the device or via [www.kobold.com](http://www.kobold.com)

## 8. Order Codes

---

Operating instructions, data sheet, approvals and further information via the QR code on the device or via [www.kobold.com](http://www.kobold.com)

## 9. Dimensions

---

Operating instructions, data sheet, approvals and further information via the QR code on the device or via [www.kobold.com](http://www.kobold.com)

## 10. Disposal


---

### Note!

- Avoid environmental damage caused by media-contaminated parts
- Dispose of the device and packaging in an environmentally friendly manner
- Comply with applicable national and international disposal regulations and environmental regulations.


### Batteries

Batteries containing pollutants are marked with a sign consisting of a crossed-out garbage can and the chemical symbol (Cd, Hg, Li or Pb) of the heavy metal that is decisive for the classification as containing pollutants:



1. „Cd" stands for cadmium
2. „Hg" stands for mercury
3. „Pb" stands for lead
4. „Li" stands for lithium

### Electrical and electronic equipment



## **11. EU Declaration of Conformance**

---

We, KOBOLD Messring GmbH, Nordring 22-24, 65719 Hofheim, Germany, declare under our sole responsibility that the product:

**Rotating-Vane Flow Indicator**

**Model: DIG-...**

to which this declaration relates is in conformity with the following EU directives stated below:

**EN IEC 63000:2018** Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances

Also, the following standards are fulfilled:

**2011/65/EU**  
**2015/863/EU**

**RoHS** (category 9)  
Delegated Directive (RoHS III)

Hofheim, 25 Sept 2023



H. Volz  
General Manager



J. Burke  
Compliance Manager

## 12. UK Declaration of Conformity

---

We, KOBOLD Messring GmbH, Nordring 22-24, 65719 Hofheim, Germany, declare under our sole responsibility that the product:

**Rotating-Vane Flow Indicator**

**Model: DIG-...**

to which this declaration relates is in conformity with the following UK directives stated below:

**S.I. 2012/3032**      The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012

Also, the following standards are fulfilled:

**BS EN IEC 63000:2018**

Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances.

Hofheim, 25 Sept 2023

Two handwritten signatures in blue ink. The first signature is on the left, and the second is on the right.

H. Volz  
General Manager

J. Burke  
Compliance Manager